


**KitchenAid®**

# COOKTOP PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)

30" Slide-In Range  
DESIGNER STYLE  
Convection Oven



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9

(White)

(Black)

(Biscuit)

(Black Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT9755235	Installation Instructions
	LIT9754288	Use & Care Guide
	LIT9754241	Tech Sheet
	LIT9754372	Wiring Diagram
	LIT9752775	Template, Anti-Tip
	LIT9753848	LP Conv Instr.
	LIT3191638	Safe Cooking Tips
	LIT4449264	Guide, Easy Set
3		Vent, Rear
	9755225PW	White
	9755225PB	Black
	9755225PC	Biscuit
4		Frame, Cooktop
	9781832PW	White
	9781832PB	Black
	9781832PC	Biscuit
5	9754197	Support, Burner
6	9751629	Bracket, Pivot
	9752003	Washer, Pivot


Illus. No.	Part No.	DESCRIPTION
7		Trim, Rear (Includes End Caps)
	9781831PW	White
	9781831PB	Black
	9781831PC	Biscuit
8	9753691	Support Clips (4)
9		Trim, Side
	9781828PW	White
	9781828PB	Black
	9781828PC	Biscuit
10	9780265	Screw, 10-16 x 3/8
12		Bezel, Burner Mouse Gray
	9753601GS	6K RF-LR
	9753602GS	12K RR
	9753600GS	14K LF Black
	9753601GB	6K RF-LR
	9753602GB	12K RR
	9753600GB	14K LF
13		Grate, Burner
	9753616GS	Mouse Gray
	9753616GB	Black

Illus. No.	Part No.	DESCRIPTION
14		Cooktop, Glass
	9753606CO	Opaque White
	9753606CB	Black
	9753606CT	Honeycomb
15	9752638	Pad, Grate (4)
17	341196	Thermo-Disc
18		Cap, Vent
	9751271GW	White
	9751271GB	Black
	9751271GC	Biscuit
19	9751366	Cap, Vent
20	9751984	Fuse, Bi-Metal
21		Cap, Burner Mouse Gray
	3191899	6K RF-LR
	3191905	12K RR
	9753939GS	14K LF Black
	3191898	6K RF-LR
	3191904	12K RR
	9753939GB	14k LF
22	9752006	Thermostat, Fixed
23	9752034	Seal, Rubber (2)
24	9754103	Gasket, Cooktop
25	9751871	Screw, 10-16 x 1
26	9754136	Pad, Cooktop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP BURNER PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Burner Base W/Orifice	7		Valve, Burner	16		Orifice, Burner
	9782447	6K RF-LR		9755345	6K, Red Stem		9753928	6K Small Base
	9782448	12K RR		9755344	12K, Black Stem		9753929	12K Medium base
	9782449	14K LF		9755405	14K, Plain Stem		9753930	14K Large Base
2	9753610	Tubing, Burner(RF)	9	9755451	Bolt, Gas Valve	18	9751854	Tubing, Flex
3	9753611	Tubing, Burner(RR)			Spark Switch & Harness Assembly	21		Head, Burner
4	9753608	Tubing, Burner(LF)	11		Manifold		4455979	6K RF-LR
5	9753609	Tubing, Burner(LR)		9782470	Left Hand		4455981	12K RR
6	9754148	Tubing, Manifold		9782471	Right Hand		4455849	14K LF
			13	9782116	Electrode	22	8281147	Screw, 8-18 x .650

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9782418CW	Console, Glass White
	9782418CB	Black
	9782418CC	Biscuit
2	9782455	Board, Display
3	9780271	Screw, 8-18 x 1/4
4		End Cap Right Hand
	9751040FW	White
	9751040FB	Black
	9751040FC	Biscuit
		Left Hand
	9751039FW	White
	9751039FB	Black
	9751039FC	Biscuit
7	9780265	Screw, 10-16 x 3/8
8		Knobs, Control (4)
	9751199FW	White
	9751199FF	Black
	9751199FC	Biscuit
10	9782435	Board, Power
11	9755021	Shield, Control Panel
23	3191387	Seal, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS


For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9

(White)

(Black)

(Biscuit)

(Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9

(White)

(Black)

(Biscuit)


(Black Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2		Trim, Door-Left	6		Vent, Door	21	9750169	Bracket, Drawer
	9782003PW	White		9753498GW	White	22	9780272	Screw, 10-16 x 1/2
	9782003PB	Black		9753498GB	Black	23	9750676	Retainer, clip
	9782003PC	Biscuit		9753498GC	Biscuit	24		Front, Drawer
3		Trim, Door-Right	7	9780265	Screw, 10-16 x 3/8		9782108PW	White
	9782004PW	White		9781659	Gasket, Door Vent		9782108PB	Black
	9782004PB	Black	8		Handle, Door		9782109PB	For Stn.Steel Mdl.
	9782004PC	Biscuit		9780523PW	White		9782108PC	Biscuit
4		Trim, Door Bottom		9780523PB	Black	25	9750693	Heat Channel
	9781209PW	White		9780523PC	Biscuit	27	423713	Support, Roller
	9781209PB	Black	9	9781449	Gasket, Door Glass		90296	Clip
	9781209PC	Biscuit	10	9782033	Hinge, Door R or L	28	9781502	Spacer, Door (8)
5		Glass, Door	12	9781602	Frame, Glass	34	9750614PB	Trim,Drawer-Top
	9781627PW	White	13	9781586	Shield Door			For Stn.Steel Mdl.
	9781627PB	Black	14	9780771	Bumper, Rubber	35	9753329	Spacer(Stn.Mdl.)
	9754041	Stainless	15	9781593	Glass, Pyro Door	36	9753293	Panel,Drawer
	9781627PC	Biscuit	16	9755177	Seal, Glass			For Stn.Steel Mdl.
			17	9780271	Screw, 8-18 x 1/4	37	9750613PB	Trim,Drawer-Btm
			18	9754006	Insulation			For Stn.Steel Mdl.
			19	9781600GM	Liner, Door			
			20	9780583	Drawer & Roller			
				9750257	For Stn.Steel Mdl.			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN CHASSIS PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN CHASSIS PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)


Illus. No.	Part No.	DESCRIPTION
1	8522426	Module, Spark
2	9750514GM	Chassis, Front
5	9753335GM	Oven Liner
6	9755179	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PB	Black
	9781907PC	Biscuit
8	9780664	Shield, Insulation
	9780265	Screw (2)
9	9751789	Fan Duct, Side
10	9780265	Screw, 10-16 x 3/8
11	9752637	Burner Box
12	9752735	Retainer, Insulation
13	9751653	Duct, Top
14	9751060	Support, Fan
15		Drawer Rail
	9750223	Left
	9750224	Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Hinge, Door L or R
21	9782051	Shield, Drawer
	340184	Screw
22	9782050	Plate, Reflectance
25	9751592	Vent Tube
29	9755192	Door Switch
30	9751808	Screw, 8-18 x 1
34	9751871	Screw, 10-16 x 1

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BROILER & OVEN BURNER PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)


Illus. No.	Part No.	DESCRIPTION
1	9752737	Shield, Oven (2)
2	9752738	Flame Shield, Bake
3	9753183	Burner, Broiler
4	9751367	Burner, Bake
6	9782065	Ignitor, Common Bake & Broil
7	9752858	Bracket, Broil Shooter
	3400075	Screw
8	9752736GM	Pan, Oven Bottom
9	9782061	Tubing, Broil
10	9752698	Valve & Regulator Assembly
12	9781015	Tubing, Valve To Regulator
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
15	9751203	Nut #18 5/8
16	9752920	Coverbox (Broiler Tubing)
17	9752716	Orifice #54
18	9751643	Screw, 10-24 x 3/8
20	9780265	Screw, 10-16 x 3/8
21	489427	Screw, 1/4 20 x 5/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9781543	Assembly, Fan
2	9780272	Screw, 10-16 x 1/2
9	9751904GM	Baffle, Convection
10	4167277	Lock-Nut, Cvr.Jack
11	4167266	Jack Cover
12	305289	Gasket


Illus. No.	Part No.	DESCRIPTION
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	8935	Bulb, Oven
16	9781050	Light, Socket
17	3150144	Probe, Meat
18	420104GM	Grill, Broiler
19	420101GM	Pan, Broiler

Illus. No.	Part No.	DESCRIPTION
20	9750827	Rack, Roasting
21	9750823	Rack, Standard (3)
22	9782081	Sensor
23	9781049	Lens, Light
24	3184533	Gasket, Lens
26	9780265	Screw, 10-16 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REAR CHASSIS PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9  
(White) (Black) (Biscuit) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back panel, Chassis
2	9755444	Suppressor, Trans
3	9751353	Panel, Rear Cover
4	112432	Nut
6	9751500	Bracket, Regulator-Valve
7	9782611	Oven Lock Assembly
12	9754291	Switch, Interloc
13	9750887	Screw, 4-40 x 1
14	9750888	Nut (2)
15	9750523	Rod, Lock
17	258076	Terminal Block
18	98884	Screw, 10-16 x 1

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MISCELLANEOUS PARTS

For Models: KGST307HWH9, KGST307HBL9, KGST307HBT9, KGST307HBS9

(White)

(Black)

(Biscuit)

(Black Stainless)

Illus. No.	Part No.	DESCRIPTION
<b><u>SPLICING WIRES--25FT. LENGTH</u></b>		
242828	Wire, Black	12 Ga. 150°C
242820	Wire, Black	14 Ga. 150°C
242821	Wire, Blue	14 Ga. 150°C
242822	Wire, Brown	14 Ga. 150°C
242830	Wire, Brown	14 Ga. 200°C
242823	Wire, Green	14 Ga. 150°C
242824	Wire, Orange	14 Ga. 150°C
242829	Wire, Red	12 Ga. 150°C
242825	Wire, Red	14 Ga. 150°C
242831	Wire, Red	14 Ga. 200°C
242826	Wire, White	14 Ga. 150°C
242827	Wire, Yellow	14 Ga. 150°C
242832	Wire, Yellow	14 Ga. 200°C
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>		
72017	White	
72107	Almond	
511873	White Porcelain	(2 Oz.)
4392899	Biscuit	
**NOTE: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.		

Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>		
350930	White	
350956	Almond	
285006	Superior Black	
206922	Primer (White)	
4392901	Biscuit	
<b><u>PAINT, BULK (1 qt.)</u></b>		
799344	White (Uncut)	
978883	Almond (Uncut)	
4392900	Biscuit(Uncut)	
<b><u>REFINISHING MATERIAL</u></b>		
799832	Kit, Porcelain Repair	(White)
242756	Touch-Up	Self-Clean (1/2 Pt.)
<b><u>INSULATION</u></b>		
9754004	Insulation, Wrap	
9754011	Insulation, Rear	
9754005	Insulation, Bottom	
9754301	Insulation, Flue	
<b><u>CLEANER, COOKTOP</u></b>		
9753543	Glass Cleaner	
3183488	Scraper	

Illus. No.	Part No.	DESCRIPTION
<b><u>ACCESSORIES</u></b>		
241430	Foil, Aluminum	Oven (18" X 25')
<b><u>CONVERSION KIT</u></b>		
9753604	Gas Conversion Kit	(LP)
9752717		(Natural)
<b><u>LUBRICANT</u></b>		
261582	Grease	
<b><u>WIRING HARNESS PARTS</u></b>		
9782465	Harness, Wire	(Main Harness)
9782460	Harness, Wire	(Neutral Gas)
9782443	Harness, Wire	(Pwr Brd to Dsply)
9782466	Harness, Wire	(Fan/BMS)
9755193	Harness, Wire	(Oven Door)
9754366	Wire, Jumper	(S/I No Bake)
9755024	Harness, Wire	(M.Probe S/I)
9751868	Grommet, Harness	
9781055	Power Cord	
690989	Screw, Ground	
9782344	Wire, Jumper	(Spark Module)
9782111	Wrap, Tie	
9781555	Clip, Wire	
20082084	Tie, Wire	
3196520	Clip, Wire	
9782454	Harness, Wire	(Dual Cooktop)
9753374	Harness, Wire	(Dual Oven Light)